



# UNIVERSAL MASTER TPMS SENSOR HARDWARE & TOOL SERVICE SET



Part No. 30000

**NO MORE GUESSING!**  
Now you can have all of the tools and hardware you need to service most TPMS sensors — right at your fingertips!

*Versatile 152-pc assortment (15 unique kits) covers over 55 different OEM sensor models & 90% of US vehicles*



- Hardware kits contain valve core & cap, mounting nut, gasket(s), washer(s), &/or valve stem
- Includes the new rubber snap-in valve stem kits with sensor screws used by GM
- Plus 50 extra valve cores / 50 extra valve caps / complete Application & Torque Guide

**TPMS service tools include:**

- Ken-Tool's unique TPMS Sentry™ sensor service tool<sup>1</sup>
  - 1/4"-drive Ratcheting Torque Wrench<sup>2</sup> with 11mm & 12mm deep Sockets<sup>3</sup> for mounting nuts
  - Torque Driver for valve cores<sup>4</sup>
  - Torque Driver<sup>5</sup> & T-10/T-15 TORX® bits for rubber snap-in valve stem self-tapping screws
- In 3" x 9" x 16" Portable Poly Case, 6-lbs. Replacement Hardware Kits Available From Ken-Tool**

**OEM HARDWARE RECOMMENDED REPLACEMENT**

Most OEM sensor manufacturers recommend that the TPMS valve hardware kit be replaced whenever the valve is removed or loosened from the sensor to ensure the system is working properly. Once the valve or sensor is loosened, original and worn components are more likely to allow air to leak or escape. Replacing old components helps the TPMS sensor function properly when the tire is remounted on the vehicle.

**TPMS Sentry™ Sensor Service Tool**

Designed to keep the sensor in a safe and secure position after the mounting nut has been removed and the sensor is released from the wheel.



Part No. 30209

KT030108

KEN-TOOL • 768 E. North Street, Akron, OH 44305  
Toll Free: 888-536-8665 • Fax: 800-872-4929 • Phone: 330-535-7177 • Fax: 330-535-1345  
E-mail: sales@kentool.com • www.kentool.com